


# DAS-R1a

## SERVICE MANUAL

West Germany Model



### SPECIFICATIONS

#### Input

Digital inputs

Connector	Connector type	Input level	Impedance
COAXIAL 1, 2	phono jack	0.5 Vp-p	75 ohms
OPTICAL 1, 2	optical connector	-18 dBm	Wavelength 660 nm
TWIN LINK	Twin link connector	--	Wavelength 800 nm

#### Output

Analog outputs

Connector	Connector type	Output level	Impedance
UNBALANCED	phono jack	2.5 V (50 kilohms)	More than 10 kilohms
BALANCED	XLR-3-32 type	2.5 V	More than 600 ohms

#### Digital audio characteristics

Number of channels	2-channel stereo
Frequency response	2 Hz – 20,000 Hz ( $\pm 0.5$ dB)
	Sampling frequency of digital signal input: 44.1 kHz
Total harmonic distortion	Less than 0.002% (at 1 kHz, Twin Link mode)
Signal-to-noise ratio	More than 117 dB
Dynamic range	More than 100 dB
Channel separation	More than 110 dB

#### General

Power requirements	AC 220 – 240 V, 50/60 Hz
Power consumption	19 W
Dimensions	470 x 125 x 410 mm (w/h/d) (18 5/8 x 5 x 16 1/4 inches)
Weight	Approx. 17 kg (37 lb. 8 oz.)

#### Accessories supplied

Stereo phono plug connecting cable (1)  
Coaxial digital connecting cable (1)

#### Optional component

CD player CDP-R1a

Design and specifications are subject to change without notice.

#### Note

This appliance conforms with EEC Directive 87/308/EEC regarding interference suppression.

**D/A CONVERTER UNIT**  
**SONY®**

## TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>
<b>1. GENERAL</b>		
General .....	3	
Location of Controls .....	4	
<b>2. DIAGRAMS</b>		
Analog & Power Block Diagram .....	5	
Digital Block Diagram .....	8	
Semiconductor Lead Layouts .....	11	
Schematic Diagram (Analog Block) .....	11	
Printed Wiring Board .....	16	
Schematic Diagram (Digital Block) .....	21	
Schematic Diagrams (Power Block) .....	24	
Waveforms .....	26	
<b>3. EXPLODED VIEWS</b>		
3-1. Cabinet Assembly .....	28	
3-2. Chassis Assembly .....	29	
<b>4. ELECTRICAL PARTS LIST</b> .....		
		31

## [Note on repair]

1. When replacing IC601, optical power adjustment (RV601) is necessary.  
Replace OPT board with adjusted new one (A-4617-285-A) because special servicing jig is necessary in this adjustment.
2. Be careful not to short output of IC601 to power side or ground side during turning on electricity.  
It causes IC broken.

## [General]

The DAS-R1a is a D/A Converter for use with the CDP-R1a CD Player, as a part of separate-type CD player system. The DAS-R1a converts the digital signal picked up from the compact disc by the CDP-R1a into an analog (audio) signal. Using the Twin Link-S system, the clock signal and data signal are transmitted separately between the DAS-R1a and the CDP-R1a. In addition, the DAS-R1a is designed to accept digital signals from a DBS (Direct Broadcasting Satellite) tuner, a DAT (Digital Audio Tape) deck, etc.

### Pulse D/A converter completely free of non-linear distortion, glitches, zero-cross distortion

Conventional D/A converters only produce sound in step-size waves; the waves are rounded through the low-pass filter, and converted to an analog (audio) signal. The pulse D/A converter of the DAS-R1a sends either a "high" signal (current on) or a "low" signal (current off). Complicated waveforms -music- is expressed by the way in which the pulse density is varied. The pulse D/A converter is theoretically free of the non-linear distortion, glitches, and zero-cross distortion that are unavoidable with conventional D/A converters. It lends a natural, warm character to the music.

### High performance LSI with high sampling speed master clock and superior calculation method

The performance of the pulse D/A converter is determined by the pulse frequency and the way in which they are calculated. The LSI adopted in the DAS-R1a achieves a maximum master clock operating frequency of as high as 50 MHz. This is two times higher than that of conventional high-speed C-MOS chips. Pulses are calculated by a unique Sony Extended Noise Shaping method to generate the high-density pulse train.

### Cauer-low-pass filter conveys all musical information without delay

The Cauer-low-pass filter instantly conveys all musical information for all bandwidths, with superior quality and ripple accuracy, echo and rejection characteristics. At the same time, the sound resolution greatly increases with the improved S/N characteristics.

# SECTION 1 GENERAL

### Carefully configured master clock and direct digital sync circuit for jitter-free sound reproduction

The master clock of the crystal oscillator is located almost directly on the pulse D/A converter to provide the purest possible clock signal. Also, a direct sync circuit is provided just ahead of the electronic switch in the last stage of the converter. The sync circuit rearranges the data along with the master clock signal. This ensures crystal-clear, powerful sound reproduction.

### Twin Link-S system for improved D/A converter time axis accuracy

The Twin Link-S system adopted in the CDP-R1a and the DAS-R1a improves the time-axis precision, giving completely jitter-free sound reproduction. The previous Sony separate-type CD player and D/A converter, the CDP-R1 and DAS-R1, set new standards for optical interface with the introduction of the "Twin Link System". In this system, the crystal oscillator is located very near the D/A converter which treats waves with the absolute minimum of distortion. In addition, bidirectional interface lines are provided; one is used to send clock timing information from the converter to the player, and the second is used to send normal data from the player to the converter. With the development of the logical synchronization circuit and optical devices, the Twin Link-S system provides jitter-free D/A conversion that ensures crystal clear and powerful sound reproduction. The Twin Link-S system and the conventional Twin Link system are interchangeable.

### Multiple terminal configurations for system expansion

The DAS-R1a has five digital inputs; one Twin-Link optical input, exclusively used for connection to the CDP-R1a, two coaxial digital inputs, and two optical inputs. Each input can be controlled independently from the front panel. For analog output, an unbalanced-type pin-jack output and a balanced-type XLR output are provided.

### To derive an effective performance from the unit

We recommend that you use the power source directly from the AC wall outlet. If you are obliged to use an extension cord, select the one which has enough current rate and selected conductives.


Be sure to get the power source from an AC wall outlet which is separated from one connected to a personal computer, electric carpet or refrigerator. Otherwise, there could be a noise problem.

Although the unit is designed against undesirable vibrations, it should be placed on a stout rack in order to avoid the vibration caused by acoustic pressure from speakers. Place the unit in a location far from a TV, VCR or tuner which may cause noise in the sound or a distortion in the picture. We recommend that you use an outdoor antenna because a room antenna tends to cause distortion.

This section is extracted  
from instruction manual.

## [Location of Controls]

Front Panel



**1 POWER switch and indicator**  
Press to turn on the power. The indicator lights in green. Press again to turn off the power and to turn out the indicator.

**2 OPERATING indicator**  
Lights in orange when the built-in digital interface is locked and the operations are performed correctly.

**3 MUTING indicator**  
Lights in orange when the unit is supplied with the power and is not in operation, with the built-in digital interface unlocked.

**4 SAMPLING FREQUENCY indicators**  
The indicator corresponding to the sampling frequency of the input program source lights in green.

32 kHz: For DBS\*-A mode, DAT 32 kHz mode, etc.  
44 kHz\*\*: For CD, etc.  
48 kHz: For DAT standard mode, etc.


**5 DIGITAL INPUT indicators**  
The indicator corresponding to the source selected by the DIGITAL INPUT selector lights in orange.

**6 DIGITAL INPUT selector**  
Selects the digital input source corresponding to the component connected to the input jacks at rear. Set to the "CD" position when used with the CDP-R1a.

\* Stands for "Direct Broadcast Satellite".  
The DAS-R1a is designed to accept the digital signals from a DBS tuner which uses PCM (digital) signals. (Only for DBS tuners providing a digital output jack which conforms to the EIAJ-format.)

\*\* The "44 kHz" indicator lights when the sampling frequency of the input digital signal is 44.1 kHz or 44.056 kHz.

Rear Panel



**1 LINE OUT (line output)/UNBALANCE jacks (phono jacks)**

Connect to the line input jacks (phono jack) of the amplifier using a phono plug connecting cable.

**2 LINE OUT (line output)/BALANCED connectors (XLR-3-32 type)**  
Connect to the line input connectors (XLR-3-31 type) of the amplifier using XLR-3 type connecting cables. This connection is less affected by external noise than the phono plug connection.

Pin assignment (CONNECTION ASSIGNMENT)



- 1: GROUND  
2: HOT (+)  
3: COLD (-)

**3 BALANCE OUT (balanced line output) ON/OFF selector**

Set to the "ON" position when using the balanced line output, and be sure to set to the "OFF" position when using the unbalanced line output.

**4 DIGITAL AUDIO INTERFACE/COAXIAL 1, 2 input jacks (phono jack)**

Connect to the coaxial digital output jacks (conforming to the Digital Audio Interface Format) of a DAT deck or CD player using the coaxial digital cable (supplied).

**5 DIGITAL AUDIO INTERFACE OPTICAL 1, 2 input connectors (optical connector)**


Connect to the optical output connectors using a optical connecting cable.

**6 DIGITAL AUDIO INTERFACE/CD/TWIN LINK input connector**

Connect to the TWIN LINK output connector of the CDP-R1a CD player using the Twin Link optical cable (supplied with the CDP-R1a).


## SECTION 2 DIAGRAMS

[Analog/Power Block Diagram]







[Digital Block Diagram]



## [Semiconductor Lead Layouts]

## Schematic Diagram] –Analog Block–

- Refer to pages 26 and 27 for Waveforms.



- I capacitors are in  $\mu\text{F}$  unless otherwise noted. pF:  $\mu\text{F}$  or V less are not indicated except for electrolytics d tantalums.

Resistors are in  $\Omega$  and  $\frac{1}{4}\text{W}$  or less unless otherwise specified.

Terminals:


  - R: bus.
  - B: bus.
  - GND: ground.
  - J: adjustment for repair.
  - P: play (CD-R/RW) port with digital output is required for recording on this set.
  - D: digital input.
  - I: black end computer disk, receive the digital signal.
  - O: white end computer disk, send the digital signal.
  - T: terminal with a VOM (input impedance  $10^6\ \Omega$ ).
  - V: voltage variations may be noted due to normal programming in tolerance.
  - GND: grounds are taken to ground in playback mode by using a licensee.
  - C: CG signal pass
  - >:
  - >:

[Semiconductor Location]

Ref. No.	Location	Ref. No.	Location
D101	E-17	IC202	H-32
D102	E-18	IC203	I-32
D103	E-13	IC204	I-28
D104	D-14	IC205	I-28
D105	D-12	IC207	H-32
D106	B-13	IC208	I-29
D107	E-15	IC301	I-31
D108	E-5	IC302	K-26
D109	B-15	IC303	I-28
D110	B-15	IC304	I-23
D111	B-15	IC305	G-26
D112	B-15	IC306	F-31
D113	A-10	IC307	F-31
D114	A-10	IC308	F-29
D202	J-28	IC309	F-29
D203	E-28	IC310	K-31
D204	E-28	IC401	G-31
D205	G-29	IC402	F-26
D301	K-24	IC403	G-26
D302	K-25	IC404	H-23
D303	K-25	IC405	K-13
D304	F-32	IC406	J-21
D305	F-32	IC407	K-14
D401	F-24	IC603	B-24
D402	F-25	IC601	B-24
D403	H-22	IC602	B-23
D404	F-32	IC604	B-23
D405	K-32	IC605	H-8
D501	H-8	Q101	B-13
D502	H-8	Q102	D-15
D503	I-8	Q103	B-15
D504	J-9	Q201	I-29
D505	J-9	Q202	J-28
D507	I-13	Q203	J-29
D508	G-13	Q204	J-29
D801	C-8	Q205	J-29
D802	C-7	Q206	G-28
D803	C-3	Q207	H-29
D804	C-2	Q208	J-31
D805	C-4	Q209	I-30
D806	C-5	Q301	J-22
D808	C-4	Q302	I-22
D809	B-4	Q303	G-21
D810	B-4	Q306	F-30
D901	B-8	Q310	K-24
I101	E-18	Q401	G-22
I102	E-18	Q402	H-21
I103	D-16	Q410	F-24
I104	B-17	Q501	G-16
I105	D-13	Q502	I-18
I106	D-14	Q503	G-16
I107	B-11	Q504	G-14
I108	B-13	Q505	I-15
I109	B-11	Q506	I-14
I110	B-13	Q507	H-16
I111	A-13	Q508	H-14
I112	B-14	Q509	I-15
I113	B-14	Q510	I-14
I114	B-14	Q511	G-13
I115	D-12	Q512	I-14
I116	D-12	Q513	G-13
I117	D-11	Q514	G-13
I118	D-11	Q515	I-13
I119	E-13	Q516	I-13
I120	E-16	Q517	K-12
I121	E-14	Q518	J-15
I122	B-15	Q520	J-16
I123	B-15	Q521	J-14
I124	B-18	Q522	J-17
I125	B-18	Q523	J-16
I126	D-14	Q524	G-18
I127	D-18	Q525	H-12
I128	B-17	Q526	I-12
I129	B-17	Q527	H-12
I201	H-30	Q527	H-12

[Printed Wiring Board]


• Refer to page 11 for Semiconductor Lead Layouts.



Note:  
 ● : parts extracted from the component side.  
 ○ : parts extracted from the conductor side.  
 • : Through hole.  
 ▲ : Pattern on the side which is seen.  
 △ : Pattern of the component side.  
 □ : Chip of the component side.

[Schematic Diagram] —Digital Block—


- Refer to page 15 for Notes.
- Refer to pages 26 and 27 for Waveforms.













[Schematic Diagram] — Power Block —


• Refer to page 15 for Notes.

1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17




[Waveforms]







⑪ IC103⑦, ②pin  
6.6Vp-p  
88kHz




⑯ IC112⑨pin  
6Vp-p  
44kHz




⑰ IC111⑨pin  
5.4Vp-p  
5.5MHz




⑫ IC103⑨pin  
6.5Vp-p  
2.7MHz




⑯ IC110①, ③pin  
IC114②pin  
4Vp-p  
44kHz




㉑ IC111⑪pin  
7Vp-p  
5.5MHz




⑬ IC103④pin  
5.5Vp-p  
44kHz




⑯ IC112①pin  
5.2Vp-p  
5.5MHz




㉓ IC110②, ⑪pin  
0.5Vp-p




㉔ IC106③pin, IC113⑨pin  
5Vp-p  
44kHz



㉕ IC112⑥pin  
6.5Vp-p  
0.34MHz



㉖ IC113①pin  
6Vp-p  
44kHz



㉗ IC112⑬pin  
5.4Vp-p  
0.34MHz

## **SECTION 3**

# **EXPLODED VIEWS**

**NOTE:**


- The mechanical parts with no reference number in the exploded views are not supplied.
  - The construction parts of an assembled part are indicated with a collation number in the remark column.
  - Items marked “★” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

- Due to standardization, parts with part number suffix -XX and -X may be different from the parts specified in the components used on the set.

- Color Indication of Appearance Parts  
Example:  
[REDF] MAINT. BALANCE (WHITE)


The components identified by mark  or dotted line with mark  are critical for safety.  
Replace only with part number specified.

### **3-1. Cabinet Assembly**



No.	Part No.	Description	Remarks	No.	Part No.	Description	Remarks
1	4-924-256-01	KNOB (B)		24	7-682-246-04	SCREW +K 3X5	
2	4-936-349-01	PANEL, FRONT		25	7-682-566-09	SCREW +B 4X20	
3	3-544-028-11	SPACER		26	7-682-548-09	SCREW +B 3X8	
4	4-924-233-01	INDICATOR		27	3-831-441-11	CUSHION	
5	9-911-840-XX	CUSHION, RUBBER		28	1-543-140-00	CORE, RING	
6	4-936-342-01	PLATE (E), ORNAMENTAL		29	7-682-550-09	SCREW +B 3X12	
7	4-936-339-01	INDICATOR		30	7-683-425-04	BOLT, HEXAGON SOCKET 4X20	
8	*4-924-254-01	HOLDER (B), LED		31	*4-924-265-01	ABSORBENT (A), ACOUSTIC	
9	4-924-245-01	PLATE (E), ORNAMENTAL		32	7-685-870-09	SCREW +BVTT 3X5 (S)	
10	X-4924-201-1	KNOB (A) ASSY		33	4-936-334-01	PLATE (K), ORNAMENTAL	
11	*X-4924-202-1	BRACKET (E) ASSY		34	7-682-546-09	SCREW +B 3X5	
12	*4-924-218-01	HOLDER (A), LED		35	*4-936-336-01	HOLDER (D), LED	
13	*4-880-426-00	SPRING, COMPRESSION		36	4-936-345-01	SPACER (G)	
14	4-862-338-00	RING, STOPPER		37	4-936-343-01	WINDOW (G)	
15	4-924-239-01	PLATE (LEFT), SIDE, ORNAMENTAL		38	4-936-346-01	PLATE (G), ORNAMENTAL	
16	4-924-240-01	PLATE (RIGHT), SIDE, ORNAMENTAL		39	*4-936-354-01	PLATE, LIGHT INTERCEPTION	
17	4-924-241-01	ESCUTCHEON (B)		40	*4-924-272-01	ABSORBENT (C), ACOUSTIC	
18	4-924-237-01	ESCUTCHEON (A)		41	9-911-835-XX	CUSHION, F	
19	4-924-242-01	SCREW (M3X6), FLAT HEAD		901	*1-633-877-11	PC BOARD, PL	
20	4-924-236-12	PANEL		902	*1-633-576-11	PC BOARD, LED	
21	*4-924-238-11	PLATE, BOTTOM		903	*1-633-878-11	PC BOARD, RSW	
22	X-4924-207-1	FOOT ASSY		919	1-543-619-41	CORE, RING	
23	3-703-685-21	SCREW (+BV 3X8)		RSW951	1-572-187-11	SWITCH, ROTARY (DIGITAL INPUT)	

### **3-2. Chassis Assembly**



No.	Part No.	Description	Remarks	No.	Part No.	Description	Remarks
51	*4-921-402-01	HEAT SINK		84	*3-701-947-08	LABEL (T500MA), FUSE	
52	7-682-148-15	SCREW, TR		85	*4-924-280-01	BOSS (E)	
53	4-924-211-01	COLLAR		86	7-623-308-07	LW 3, TYPE (A)	
54	4-936-305-01	BUSHING		87	X-4908-910-1	SCREW ASSY (+ BVTT)	
55	4-924-264-01	TERMINAL, MOUNT		88	7-682-147-15	SCREW, TR	
56	3-704-208-01	BAND, BINDING		89	9-911-815-02	CUSHION, BATTERY LID	
57	3-655-653-21	BAND (TAITON), BINDING		904	*A-4617-288-A	MOUNTED PCB, POWER	51,52
58	*4-924-274-01	REINFORCEMENT		905	*A-4617-542-A	MOUNTED PCB, ANALOG	55,59,80,81
59	2-269-798-01	HEAT SINK, TO-39		906	*A-4617-672-A	MOUNTED PCB, DIGITAL	52,55
60	*4-941-263-02	PANEL (F), BACK		907	*1-628-540-11	PC BOARD, FUSE	
61	▲.*X-4885-924-1	BUSHING ASSY, CORD		908	*1-633-879-11	PC BOARD, SSW	
62	4-916-726-01	WASHER		909	*1-633-704-11	PC BOARD, (B) OUT	
63	3-831-441-11	CUSHION		910	*1-633-880-11	PC BOARD, U-OUT	
64	*4-936-340-01	PLATE (T), ORNAMENTAL		911	*A-4617-285-A	MOUNTED PCB, OPT	
65	3-703-685-21	SCREW (+BV 3X8)		912	*1-633-629-11	PC BOARD, LINE TRANSFORMER	
66	7-682-547-09	SCREW +B 3X6		913	1-533-183-11	HOLDER, FUSE	
67	7-682-546-09	SCREW +B 3X5		914	▲.1-559-271-11	CORD, POWER	
68	7-684-023-04	N 3, TYPE 2		915	1-535-139-00	BASE POST 22MM (10MM PITCH) 2P	
69	7-682-550-09	SCREW +B 3X12		916	*1-535-141-00	BASE POST 22MM (10MM PITCH) 4P	
70	7-682-548-09	SCREW (3X8)		917	1-535-476-11	TERMINAL	
71	7-682-563-09	SCREW +B 4X12		918	*1-635-954-11	PC BOARD, LINE FILTER	
72	*4-924-271-01	ABSORBENT (B), ACOUSTIC		CN001	1-569-256-11	CONNECTOR (RECEPTACLE)(BALANCE OUT L)	
73	7-682-148-15	SCREW, TR		CN002	1-569-256-11	CONNECTOR (RECEPTACLE)(BALANCE OUT R)	
74	7-621-775-20	SCREW +B 2.6X5		F701	▲.1-532-279-00	FUSE, TIME-LAG (T500MA)	
75	7-682-249-04	SCREW +K 3X10		F702	▲.1-532-066-00	FUSE, TIME-LAG (T400MA)	
76	3-831-441-11	SPACER (10X160X0.5)		J101	1-568-918-41	JACK, PIN 1P (LINE OUT L)	
77	3-645-258-00	CLOTH, GUIDE, C		J102	1-568-918-31	JACK, PIN 1P (LINE OUT R)	
78	2-371-561-00	BUSHING (P), INSULATING		J103	1-568-918-21	JACK, PIN 1P (COAXIAL 1)	
79	*3-655-862-11	SPACER, INSULATING		J104	1-568-918-21	JACK, PIN 1P (COAXIAL 2)	
80	9-911-863-XX	SPACER		SSW901	1-571-083-31	SWITCH, SLIDE (BALANCE OUT)	
81	*3-683-631-01	CLAMP		SW701	▲.1-554-538-00	SWITCH, PUSH (AC POWER)(1 KEY)	
82	4-870-539-00	PLATE, GROUND		T101	▲.1-449-427-11	TRANSFORMER, POWER	
83	*3-701-948-10	LABEL (T400MA), FUSE		T102	▲.1-450-196-11	TRANSFORMER, POWER	

The components identified by mark ▲ or dotted line with mark ▲ are critical for safety.  
Replace only with part number specified.

## SECTION 4

### ELECTRICAL PARTS LIST

**NOTE:**

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- Items marked “★” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- If there are two or more same circuits in a set such as a stereophonic machine, only typical circuit parts may be indicated and capacitors and resistors in other same circuits may be omitted.

**CAPACITORS:**  
MF:  $\mu\text{F}$ , PF:  $\mu\mu\text{F}$ .

**RESISTORS**

- All resistors are in ohms.
- F: nonflammable

**COILS**

- MMH: mH, UH:  $\mu\text{H}$

**SEMICONDUCTORS**

In each case, U:  $\mu$ , for example:  
UA...:  $\mu\text{A}$ ..., UPA...:  $\mu\text{PA}$ ...,  
UPC...:  $\mu\text{PC}$ , UPD...:  $\mu\text{PD}$ ...

The components identified by mark  or dotted line with mark  are critical for safety.  
Replace only with part number specified.

Ref.No.	Part No.	Description			Ref.No.	Part No.	Description			
901	*1-633-877-11	PC BOARD, PL			C107	1-162-179-11	CERAMIC	0.1MF	50V	
902	*1-633-576-11	PC BOARD, LED			C108	1-107-202-00	MICA	10PF	0.5PF 500V	
903	*1-633-878-11	PC BOARD, RSW			C109	1-136-169-00	FILM	0.22MF	5% 50V	
904	*A-4617-288-A	OUNTED PCB, POWER	51,52		C110	1-106-359-00	MYLAR	0.0047MF	5% 50V	
905	*A-4617-542-A	OUNTED PCB, ANALOG	55,59,80,81		C111	1-107-210-00	MICA	22PF	5% 500V	
906	*A-4617-672-A	OUNTED PCB, DIGITAL	52,55		C112	1-107-210-00	MICA	22PF	5% 500V	
907	*1-628-540-11	PC BOARD, FUSE			C113	1-136-165-00	FILM	0.1MF	5% 50V	
908	*1-633-879-11	PC BOARD, SSW			C114	1-136-165-00	FILM	0.1MF	5% 50V	
909	*1-633-704-11	PC BOARD, (B) OUT			C115	1-124-024-00	ELECT	220MF	20% 10V	
910	*1-633-880-11	PC BOARD, U-OUT			C116	1-162-179-11	CERAMIC	0.1MF	50V	
911	*A-4617-285-A	OUNTED PCB, OPT			C117	1-136-165-00	FILM	0.1MF	5% 50V	
912	*1-633-629-11	PC BOARD, LINE TRANSFORMER			C118	1-126-058-11	ELECT	4.7MF	20% 50V	
913	1-533-183-11	HOLDER, FUSE			C119	1-162-179-11	CERAMIC	0.1MF	50V	
914	A.1-559-271-11	CORD, POWER			C120	1-126-058-11	ELECT	4.7MF	20% 50V	
915	1-535-139-00	BASE POST 22MM (10MM PITCH) 2P			C121	1-126-045-11	ELECT	2.2MF	20% 50V	
916	*1-535-141-00	BASE POST 22MM (10MM PITCH) 4P			C122	1-162-179-11	CERAMIC	0.1MF	50V	
917	1-535-476-11	TERMINAL			C123	1-162-179-11	CERAMIC	0.1MF	50V	
918	*1-635-954-11	PC BOARD, LINE FILTER			C124	1-136-165-00	FILM	0.1MF	5% 50V	
919	1-543-619-41	CORE, RING			C125	1-107-169-00	MICA	100PF	5% 500V	
BB101	1-565-062-11	BAR, BUS			C126	1-162-179-11	CERAMIC	0.1MF	50V	
BB102	*1-569-237-11	BAR, BUS 8P			C127	1-162-179-11	CERAMIC	0.1MF	50V	
BB103	*1-569-237-11	BAR, BUS 8P			C128	1-162-179-11	CERAMIC	0.1MF	50V	
BB301	1-565-063-11	BAR, BUS			C129	1-162-179-11	CERAMIC	0.1MF	50V	
BB302	*1-569-236-11	BAR, BUS 6P			C130	1-124-024-00	ELECT	220MF	20% 10V	
BB303	*1-569-236-11	BAR, BUS 6P			C131	1-162-179-11	CERAMIC	0.1MF	50V	
BB304	*4-913-106-01	REINFORCEMENT (C), PWB			C132	1-136-173-00	FILM	0.47MF	5% 50V	
BB305	*1-569-235-11	BAR, BUS 5P			C133	1-107-210-00	MICA	22PF	5% 500V	
BB306	*1-566-940-11	BUS BAR 6P			C134	1-107-210-00	MICA	22PF	5% 500V	
BB307	*1-580-302-11	BAR, BUS 4P			C135	1-162-179-11	CERAMIC	0.1MF	50V	
BB308	*1-569-137-11	BUS BAR 2P			C136	1-124-024-00	ELECT	220MF	20% 10V	
BB309	*1-569-137-11	BUS BAR 2P			C137	1-162-179-11	CERAMIC	0.1MF	50V	
BB501	1-565-062-11	BAR, BUS			C138	1-130-481-00	MYLAR	0.0068MF	5% 50V	
BB502	1-569-360-11	BAR, BUS			C139	1-162-179-11	CERAMIC	0.1MF	50V	
BP201	*1-535-114-00	TERMINAL			C140	1-126-024-11	ELECT	220MF	20% 16V	
BP301	*1-535-117-00	TERMINAL			C141	1-162-179-11	CERAMIC	0.1MF	50V	
BP401	*1-535-117-00	TERMINAL			C142	1-126-051-11	ELECT	47MF	20% 50V	
BP501	*1-535-140-00	BASE POST 22MM (10MM PITCH) 3P			C143	1-126-051-11	ELECT	47MF	20% 50V	
BP502	*1-535-140-00	BASE POST 22MM (10MM PITCH) 3P			C144	1-162-179-11	CERAMIC	0.1MF	50V	
BP503	*1-535-121-00	TERMINAL			C145	1-126-024-11	ELECT	220MF	20% 16V	
BP720	*1-535-139-00	BASE POST 19MM (10MM PITCH) 2P			C146	1-162-179-11	CERAMIC	0.1MF	50V	
C101	1-136-177-00	FILM	1MF	5%	50V	C147	1-126-051-11	ELECT	47MF	20% 50V
C102	1-136-177-00	FILM	1MF	5%	50V	C148	1-126-051-11	ELECT	47MF	20% 50V
C103	1-162-179-11	CERAMIC	0.1MF		C149	1-126-024-11	ELECT	220MF	20% 16V	
C104	1-124-024-00	ELECT	220MF	20%	10V	C150	1-162-179-11	CERAMIC	0.1MF	50V
C105	1-162-179-11	CERAMIC	0.1MF		C151	1-124-024-00	ELECT	220MF	20% 10V	
C106	1-124-024-00	ELECT	220MF	20%	10V	C152	1-126-024-11	ELECT	220MF	20% 16V

Ref.No.	Part No.	Description					Ref.No.	Part No.	Description			
C153	1-136-173-00	FILM	0.47MF	5%	50V		C305	1-126-023-11	ELECT	100MF	20%	25V
C154	1-136-173-00	FILM	0.47MF	5%	50V		C307	1-136-961-11	FILM	0.047MF	10%	160V
C155	1-162-306-11	CERAMIC	0.01MF	20%	16V		C308	1-126-023-11	ELECT	100MF	20%	25V
C156	1-162-306-11	CERAMIC	0.01MF	20%	16V		C309	1-136-961-11	FILM	0.047MF	10%	160V
C157	1-162-179-11	CERAMIC	0.1MF		50V		C310	1-126-023-11	ELECT	100MF	20%	25V
C158	1-162-179-11	CERAMIC	0.1MF		50V		C313	1-136-961-11	FILM	0.047MF	10%	160V
C161	1-162-179-11	CERAMIC	0.1MF		50V		C315	1-109-542-00	MICA	220PF	2%	100V
C170	1-162-283-31	CERAMIC	120PF	10%	50V		C316	1-109-542-00	MICA	220PF	2%	100V
C201	1-124-130-00	ELECT	100MF	20%	63V		C317	1-136-810-11	FILM	220PF	5%	100V
C202	1-136-165-00	FILM	0.1MF	5%	50V		C318	1-136-810-11	FILM	220PF	5%	100V
C203	1-136-165-00	FILM	0.1MF	5%	50V		C319	1-107-324-00	MICA	0.0039MF	2%	100V
C204	1-125-605-11	ELECT	1500MF	20%	63V		C320	1-107-324-00	MICA	0.0039MF	2%	100V
C206	1-107-202-00	MICA	10PF	0.5PF	500V		C321	1-107-074-00	MICA	36PF	2%	100V
C207	1-107-202-00	MICA	10PF	0.5PF	500V		C322	1-107-208-00	MICA	18PF	2%	100V
C208	1-126-052-11	ELECT	100MF	20%	25V		C323	1-107-344-11	MICA	3000PF	2%	100V
C209	1-136-177-00	FILM	1MF	5%	50V		C324	1-136-764-11	FILM	10MF	10%	100V
C210	1-162-179-11	CERAMIC	0.1MF		50V		C325	1-136-764-11	FILM	10MF	10%	100V
C211	1-126-052-11	ELECT	100MF	20%	25V		C326	1-109-631-00	MICA	330PF	2%	500V
C212	1-107-210-00	MICA	22PF	5%	500V		C327	1-109-557-00	MICA	680PF	2%	100V
C213	1-107-210-00	MICA	22PF	5%	500V		C328	1-125-605-11	ELECT	1500MF	20%	63V
C214	1-136-173-00	FILM	0.47MF	5%	50V		C351	1-136-961-11	FILM	0.047MF	10%	160V
C215	1-130-481-00	MYLAR	0.0068MF	5%	50V		C352	1-136-961-11	FILM	0.047MF	10%	160V
C216	1-162-211-31	CERAMIC	33PF	5%	50V		C353	1-136-961-11	FILM	0.047MF	10%	160V
C217	1-162-199-31	CERAMIC	10PF	5%	50V		C354	1-136-961-11	FILM	0.047MF	10%	160V
C218	1-162-207-31	CERAMIC	22PF	5%	50V		C355	1-136-961-11	FILM	0.047MF	10%	160V
C219	1-136-153-00	FILM	0.01MF	5%	50V		C356	1-136-961-11	FILM	0.047MF	10%	160V
C220	1-131-450-00	TANTALUM	1MF	20%	50V		C380	1-136-174-00	FILM	0.56MF	5%	50V
C221	1-162-193-31	CERAMIC	3.3PF	10%	50V		C401	1-136-961-11	FILM	0.047MF	10%	160V
C222	1-136-153-00	FILM	0.01MF	5%	50V		C405	1-136-961-11	FILM	0.047MF	10%	160V
C223	1-131-450-00	TANTALUM	1MF	20%	50V		C406	1-126-023-11	ELECT	100MF	20%	25V
C224	1-130-471-00	MYLAR	0.001MF	5%	50V		C407	1-136-961-11	FILM	0.047MF	10%	160V
C225	1-136-157-00	FILM	0.022MF	5%	50V		C408	1-126-023-11	ELECT	100MF	20%	25V
C230	1-136-173-00	FILM	0.47MF	5%	50V		C409	1-136-961-11	FILM	0.047MF	10%	160V
C231	1-162-179-11	CERAMIC	0.1MF		50V		C410	1-126-023-11	ELECT	100MF	20%	25V
C232	1-162-179-11	CERAMIC	0.1MF		50V		C413	1-136-961-11	FILM	0.047MF	10%	160V
C233	1-126-052-11	ELECT	100MF	20%	25V		C415	1-109-542-00	MICA	220PF	2%	100V
C234	1-136-165-00	FILM	0.1MF	5%	50V		C416	1-109-542-00	MICA	220PF	2%	100V
C235	1-162-179-11	CERAMIC	0.1MF		50V		C417	1-136-810-11	FILM	220PF	5%	100V
C240	1-123-369-00	ELECT	4.7MF	20%	63V		C418	1-136-810-11	FILM	220PF	5%	100V
C241	1-123-369-00	ELECT	4.7MF	20%	63V		C419	1-107-324-00	MICA	0.0039MF	2%	100V
C245	1-126-023-11	ELECT	100MF	20%	25V		C420	1-107-324-00	MICA	0.0039MF	2%	100V
C250	1-126-023-11	ELECT	100MF	20%	25V		C421	1-107-074-00	MICA	36PF	2%	100V
C251	1-126-023-11	ELECT	100MF	20%	25V		C422	1-107-208-00	MICA	18PF	2%	100V
C252	1-126-023-11	ELECT	100MF	20%	25V		C423	1-107-344-11	MICA	3000PF	2%	100V
C253	1-126-023-11	ELECT	100MF	20%	25V		C424	1-136-764-11	FILM	10MF	10%	100V
C254	1-126-023-11	ELECT	100MF	20%	25V		C425	1-136-764-11	FILM	10MF	10%	100V
C255	1-126-023-11	ELECT	100MF	20%	25V		C426	1-109-631-00	MICA	330PF	2%	500V
C256	1-136-153-00	FILM	0.01MF	5%	50V		C427	1-109-557-00	MICA	680PF	2%	100V
C257	1-136-153-00	FILM	0.01MF	5%	50V		C428	1-125-605-11	ELECT	1500MF	20%	63V
C258	1-136-961-11	FILM	0.047MF	10%	160V		C451	1-136-961-11	FILM	0.047MF	10%	160V
C259	1-136-961-11	FILM	0.047MF	10%	160V		C452	1-136-961-11	FILM	0.047MF	10%	160V
C260	1-136-961-11	FILM	0.047MF	10%	160V		C453	1-136-961-11	FILM	0.047MF	10%	160V
C261	1-136-961-11	FILM	0.047MF	10%	160V		C454	1-136-961-11	FILM	0.047MF	10%	160V
C262	1-162-306-11	CERAMIC	0.01MF	20%	16V		C455	1-136-961-11	FILM	0.047MF	10%	160V
C263	1-162-306-11	CERAMIC	0.01MF	20%	16V		C456	1-136-961-11	FILM	0.047MF	10%	160V
C301	1-136-961-11	FILM	0.047MF	10%	160V		C480	1-136-174-00	FILM	0.56MF	5%	50V
C305	1-136-961-11	FILM	0.047MF	10%	160V		C501	1-136-880-11	FILM	2.2MF	10%	160V

Ref.No.	Part No.	Description			Ref.No.	Part No.	Description	
C502	1-136-961-11	FILM	0.047MF	10%	160V	CN108	*1-564-509-11	PLUG, CONNECTOR 6P
C503	1-125-598-11	ELECT	4700MF	20%	63V	CN109	*1-564-510-11	PLUG, CONNECTOR 7P
C504	1-125-598-11	ELECT	4700MF	20%	63V	CN110	*1-564-506-11	PLUG, CONNECTOR 3P
C505	1-126-045-11	ELECT	2.2MF	20%	50V	CN111	*1-564-509-11	PLUG, CONNECTOR 6P
C506	1-126-736-11	ELECT	22MF	20%	100V	CN112	*1-564-510-11	PLUG, CONNECTOR 7P
C507	1-136-173-00	FILM	0.47MF	5%	50V	CN201	*1-564-509-11	PLUG, CONNECTOR 6P
C508	1-126-060-11	ELECT	22MF	20%	50V	CN202	*1-564-508-11	PLUG, CONNECTOR 5P
C509	1-136-153-00	FILM	0.01MF	5%	50V	CN203	*1-564-511-11	PLUG, CONNECTOR 8P
C512	1-136-880-11	FILM	2.2MF	10%	160V	CN204	*1-564-506-11	PLUG, CONNECTOR 3P
C513	1-136-960-11	FILM	0.1MF	10%	160V	CN301	*1-564-506-11	PLUG, CONNECTOR 3P
C514	1-125-604-11	ELECT	4700MF	20%	63V	CN302	*1-564-506-11	PLUG, CONNECTOR 3P
C515	1-125-604-11	ELECT	4700MF	20%	63V	CN303	*1-564-507-11	PLUG, CONNECTOR 4P
C516	1-125-604-11	ELECT	4700MF	20%	63V	CN401	*1-564-506-11	PLUG, CONNECTOR 3P
C517	1-125-604-11	ELECT	4700MF	20%	63V	CN402	*1-564-506-11	PLUG, CONNECTOR 3P
C518	1-126-051-11	ELECT	47MF	20%	63V	CN403	*1-564-507-11	PLUG, CONNECTOR 4P
C519	1-126-051-11	ELECT	47MF	20%	63V	CN501	*1-564-510-11	PLUG, CONNECTOR 7P
C520	1-124-918-11	ELECT	47MF	20%	63V	CN601	*1-564-509-11	PLUG, CONNECTOR 6P
C521	1-124-918-11	ELECT	47MF	20%	63V	CN701	*1-564-519-11	PLUG, CONNECTOR 4P
C522	1-124-918-11	ELECT	47MF	20%	63V	CN702	*1-564-519-11	PLUG, CONNECTOR 4P
C523	1-124-918-11	ELECT	47MF	20%	63V	CN801	*1-564-522-11	PLUG, CONNECTOR 7P
C524	1-109-559-00	MICA	820PF	2%	100V	CN802	*1-564-521-11	PLUG, CONNECTOR 6P
C525	1-109-559-00	MICA	820PF	2%	100V	CN803	*1-564-518-11	PLUG, CONNECTOR 3P
C526	1-125-605-11	ELECT	1500MF	20%	63V	CN901	*1-564-518-11	PLUG, CONNECTOR 3P
C527	1-125-605-11	ELECT	1500MF	20%	63V	CN951	*1-564-510-11	PLUG, CONNECTOR 7P
C528	1-136-960-11	FILM	0.1MF	10%	160V	D101	8-719-123-78	DIODE 1SS97-2
C529	1-136-960-11	FILM	0.1MF	10%	160V	D102	8-719-123-78	DIODE 1SS97-2
C530	1-126-051-11	ELECT	47MF	20%	63V	D103	8-719-912-20	DIODE 1SS120
C531	1-126-051-11	ELECT	47MF	20%	63V	D104	8-719-912-20	DIODE 1SS120
C532	1-126-051-11	ELECT	47MF	20%	63V	D105	8-719-912-20	DIODE 1SS120
C533	1-136-153-00	FILM	0.01MF	5%	50V	D106	8-719-912-20	DIODE 1SS120
C601	1-162-179-11	CERAMIC	0.1MF		50V	D108	8-719-123-78	DIODE 1SS97-2
C602	1-162-179-11	CERAMIC	0.1MF		50V	D109	8-719-200-02	DIODE 10E2
C603	1-162-179-11	CERAMIC	0.1MF		50V	D110	8-719-200-02	DIODE 10E2
C604	1-162-179-11	CERAMIC	0.1MF		50V	D111	8-719-200-02	DIODE 10E2
C605	1-126-735-11	ELECT	33MF	20%	63V	D112	8-719-200-02	DIODE 10E2
C701 △	1-161-744-00	CERAMIC	0.01MF		400V	D113	8-719-912-20	DIODE 1SS120
C720 △	1-161-744-00	CERAMIC	0.01MF		400V	D114	8-719-912-20	DIODE 1SS120
C721 △	1-161-744-00	CERAMIC	0.01MF		400V	D202	8-719-123-78	DIODE 1SS97-2
C722 △	1-161-744-00	CERAMIC	0.01MF		400V	D203	8-719-901-59	DIODE KV1320
C723 △	1-161-744-00	CERAMIC	0.01MF		400V	D204	8-719-903-27	DIODE 1SS168
C801	1-136-153-00	FILM	0.01MF	5%	50V	D205	8-719-933-33	DIODE HZS6A1L
C802	1-136-153-00	FILM	0.01MF	5%	50V	D301	8-719-912-20	DIODE 1SS120
C803	1-136-153-00	FILM	0.01MF	5%	50V	D302	8-719-912-20	DIODE 1SS120
C804	1-136-153-00	FILM	0.01MF	5%	50V	D303	8-719-300-04	DIODE SV-04
C805	1-136-153-00	FILM	0.01MF	5%	50V	D304	8-719-912-20	DIODE 1SS120
C806	1-136-153-00	FILM	0.01MF	5%	50V	D305	8-719-912-20	DIODE 1SS120
C807	1-136-153-00	FILM	0.01MF	5%	50V	D401	8-719-912-20	DIODE 1SS120
C808	1-136-153-00	FILM	0.01MF	5%	50V	D402	8-719-912-20	DIODE 1SS120
C809	1-136-153-00	FILM	0.01MF	5%	50V	D403	8-719-300-04	DIODE SV-04
C810	1-136-153-00	FILM	0.01MF	5%	50V	D404	8-719-912-20	DIODE 1SS120
C901	1-136-153-00	FILM	0.01MF	5%	50V	D405	8-719-912-20	DIODE 1SS120
CN001	1-569-256-11	CONNECTOR (RECEPTACLE) (BALANCE OUT L)				D501	8-719-200-39	DIODE C16P20F
CN002	1-569-256-11	CONNECTOR (RECEPTACLE) (BALANCE OUT R)				D502	8-719-200-40	DIODE C16P20FR
CN101	*1-564-511-11	PLUG, CONNECTOR 8P				D503	8-719-200-39	DIODE C16P20F
CN105	*1-564-508-11	PLUG, CONNECTOR 5P				D504	8-719-911-55	DIODE U05G
CN106	*1-564-509-11	PLUG, CONNECTOR 6P				D505	8-719-911-55	DIODE U05G
CN107	*1-564-510-11	PLUG, CONNECTOR 7P				D507	8-719-931-07	DIODE EQB01-07

The components identified by mark ▲ or dotted line with mark △ are critical for safety.  
Replace only with part number specified.

Ref.No.	Part No.	Description	Ref.No.	Part No.	Description
D508	8-719-931-07	DIODE EQB01-07	IC307	8-719-902-56	DIODE PC817
D801	8-719-302-07	DIODE SEL1810A	IC308	8-719-902-56	DIODE PC817
D802	8-719-302-07	DIODE SEL1810A	IC309	8-719-902-56	DIODE PC817
D803	8-719-302-07	DIODE SEL1810A	IC310	8-719-902-56	DIODE PC817
D804	8-719-302-07	DIODE SEL1810A	IC401	8-752-335-51	IC CXD2552Q-1
D805	8-719-302-07	DIODE SEL1810A	IC402	8-759-971-80	IC AD712JN
D806	8-719-302-07	DIODE SEL1810A	IC403	8-759-932-31	IC LF356H-K
D807	8-719-302-07	DIODE SEL1810A	IC404	8-759-971-80	IC AD712JN
D808	8-719-303-02	DIODE SEL2510C-D	IC501	8-759-916-20	IC SN74HC14N
D809	8-719-303-02	DIODE SEL2510C-D	IC502	8-759-982-21	IC RC78L05A
D810	8-719-303-02	DIODE SEL2510C-D	IC503	8-759-982-21	IC RC78L05A
D901	8-719-303-02	DIODE SEL2510C-D	IC601	8-759-239-30	IC F428I
F701	▲.1-532-279-00	FUSE, TIME-LAG (T500mA)	IC602	8-759-239-32	IC TORX173
F702	▲.1-532-066-00	FUSE, TIME-LAG (T400mA)	IC603	8-759-239-32	IC TORX173
IC101	8-759-233-64	IC TC74HC04AF	J101	1-568-918-41	JACK, PIN 1P (LINE OUT L)
IC102	8-759-032-01	IC MC74HC00AF	J102	1-568-918-31	JACK, PIN 1P (LINE OUT R)
IC103	8-759-994-60	IC CXD2900Q	J103	1-568-918-21	JACK, PIN 1P (COAXIAL 1)
IC104	8-752-328-61	IC CXD1244S	J104	1-568-918-21	JACK, PIN 1P (COAXIAL 2)
IC105	8-759-925-76	IC SN74HC08NS	L101	1-408-113-00	INDUCTOR 4.7UH
IC106	8-759-232-32	IC TC74HC74AF	L102	1-408-113-00	INDUCTOR 4.7UH
IC107	8-759-206-28	IC TC74HC123F	L103	1-408-912-11	INDUCTOR 1MMH
IC108	8-759-925-80	IC SN74HC14NS	L104	1-408-113-00	INDUCTOR 4.7UH
IC109	8-759-032-01	IC MC74HC00AF	L105	1-408-113-00	INDUCTOR 4.7UH
IC110	8-759-040-44	IC MC4044P	L106	1-408-113-00	INDUCTOR 4.7UH
IC111	8-759-232-36	IC TC74HC76AF	L107	1-410-513-11	INDUCTOR 22UH
IC112	8-759-233-26	IC TC74HC393AF	L108	1-410-324-11	INDUCTOR 4.7UH
IC113	8-759-032-01	IC MC74HC00AF	L109	1-410-513-11	INDUCTOR 22UH
IC114	8-759-925-76	IC SN74HC08NS	L110	1-410-513-11	INDUCTOR 22UH
IC115	8-759-645-16	IC M54516P	L201	1-410-513-11	INDUCTOR 22UH
IC116	8-759-645-16	IC M54516P	L202	1-460-042-11	COIL (WITH CORE)
IC117	8-759-925-72	IC SN74HC02NS	L203	1-460-042-11	COIL (WITH CORE)
IC118	8-759-032-01	IC MC74HC00AF	L204	1-408-095-00	INDUCTOR 470UH
IC119	8-759-925-85	IC SN74HC32NS	L205	1-410-509-11	INDUCTOR 10UH
IC120	8-759-971-80	IC AD712JN	L206	1-410-509-11	INDUCTOR 10UH
IC121	8-759-982-21	IC RC78L05A	L207	1-410-509-11	INDUCTOR 10UH
IC122	8-759-971-80	IC AD712JN	L208	1-410-509-11	INDUCTOR 10UH
IC123	8-759-982-21	IC RC78L05A	L211	*1-410-858-11	INDUCTOR 0UH
IC124	8-752-334-77	IC CXD2553S	L212	*1-410-858-11	INDUCTOR 0UH
IC125	8-759-925-74	IC SN74HC04NS	L601	1-408-072-00	INDUCTOR 47UH
IC126	8-759-604-29	IC M5F7805L	L602	1-408-072-00	INDUCTOR 47UH
IC127	8-759-233-66	IC TC74HCT04AF	L603	1-408-072-00	INDUCTOR 47UH
IC128	8-759-925-74	IC SN74HC04NS	L720	1-424-404-11	COIL, LINE FILTER
IC129	8-759-925-85	IC SN74HC32NS	Q101	8-729-119-78	TRANSISTOR 2SC2785-HFE
IC201	8-759-233-64	IC TC74HC04AF	Q102	8-729-107-53	TRANSISTOR 2SC2275A
IC202	8-759-032-01	IC MC74HC00AF	Q103	8-729-107-53	TRANSISTOR 2SC2275A
IC203	8-759-242-57	IC TC74HC4020AF	Q201	8-729-119-76	TRANSISTOR 2SA1175-HFE
IC204	8-759-013-39	IC MC4044M	Q202	8-729-119-78	TRANSISTOR 2SC2785-HFE
IC205	8-759-242-57	IC TC74HC4020AF	Q203	8-729-200-56	TRANSISTOR 2SK241GR
IC206	8-759-971-80	IC AD712JN	Q204	8-729-200-56	TRANSISTOR 2SK241GR
IC207	8-759-634-55	IC M5F7805L-720	Q205	8-729-900-61	TRANSISTOR DTA114ES
IC208	8-759-233-64	IC TC74HC04AF	Q206	8-729-107-53	TRANSISTOR 2SC2275A
IC301	8-752-335-51	IC CXD2552Q-1	Q207	8-729-119-76	TRANSISTOR 2SA1175-HFE
IC302	8-759-971-80	IC AD712JN	Q208	8-729-140-96	TRANSISTOR 2SD774-34
IC303	8-759-932-31	IC LF356H-K	Q209	8-729-200-56	TRANSISTOR 2SK241GR
IC304	8-759-971-80	IC AD712JN	Q301	8-729-200-56	TRANSISTOR 2SK241GR
IC306	8-719-902-56	DIODE PC817	Q302	8-729-321-35	TRANSISTOR 2SK213
			Q303	8-729-307-65	TRANSISTOR 2SJ76

The components identified by mark ▲ or dotted line with mark ▲ are critical for safety.  
Replace only with part number specified.

Ref.No.	Part No.	Description	Ref.No.	Part No.	Description
Q305	8-729-140-96	TRANSISTOR 2SD774-34	R123	1-259-484-11	CARBON 220K 5% 1/6W
Q306	8-729-140-96	TRANSISTOR 2SD774-34	R124	1-259-492-11	CARBON 470K 5% 1/6W
Q310	8-729-201-05	TRANSISTOR 2SC2878B.	R125	1-259-428-11	CARBON 1K 5% 1/6W
Q401	8-729-200-56	TRANSISTOR 2SK241GR	R126	1-259-452-11	CARBON 10K 5% 1/6W
Q402	8-729-321-35	TRANSISTOR 2SK213	R127	1-259-428-11	CARBON 1K 5% 1/6W
Q403	8-729-307-65	TRANSISTOR 2SJ76	R128	1-259-426-11	CARBON 820 5% 1/6W
Q410	8-729-201-05	TRANSISTOR 2SC2878B	R129	1-259-428-11	CARBON 1K 5% 1/6W
Q501	8-729-107-53	TRANSISTOR 2SC2275A	R130	1-259-428-11	CARBON 1K 5% 1/6W
Q502	8-729-190-53	TRANSISTOR 2SA985A	R131	1-259-444-11	CARBON 4.7K 5% 1/6W
Q503	8-729-104-91	TRANSISTOR 2SA1383-Q	R132	1-259-444-11	CARBON 4.7K 5% 1/6W
Q504	8-729-104-91	TRANSISTOR 2SA1383-Q	R133	1-259-456-11	CARBON 15K 5% 1/6W
Q505	8-729-104-18	TRANSISTOR 2SC3514-Q	R134	1-259-428-11	CARBON 1K 5% 1/6W
Q506	8-729-104-18	TRANSISTOR 2SC3514-Q	R135	1-259-428-11	CARBON 1K 5% 1/6W
Q507	8-729-104-18	TRANSISTOR 2SC3514-Q	R136	1-259-426-11	CARBON 820 5% 1/6W
Q508	8-729-104-18	TRANSISTOR 2SC3514-Q	R137	1-259-420-11	CARBON 470 5% 1/6W
Q509	8-729-104-91	TRANSISTOR 2SA1383-Q	R138	1-259-420-11	CARBON 470 5% 1/6W
Q510	8-729-104-91	TRANSISTOR 2SA1383-Q	R139	1-259-420-11	CARBON 470 5% 1/6W
Q511	8-729-238-32	TRANSISTOR 2SC2383	R140	1-259-420-11	CARBON 470 5% 1/6W
Q512	8-729-304-92	TRANSISTOR 2SB649A	R141	1-259-420-11	CARBON 470 5% 1/6W
Q513	8-729-304-92	TRANSISTOR 2SB649A	R142	1-259-420-11	CARBON 470 5% 1/6W
Q514	8-729-304-92	TRANSISTOR 2SB649A	R143	1-259-404-11	CARBON 100 5% 1/6W
Q515	8-729-238-32	TRANSISTOR 2SC2383	R144	1-259-404-11	CARBON 100 5% 1/6W
Q516	8-729-238-32	TRANSISTOR 2SC2383	R145	1-259-404-11	CARBON 100 5% 1/6W
Q517	8-729-119-78	TRANSISTOR 2SC2785-HFE	R146	1-259-404-11	CARBON 100 5% 1/6W
Q518	8-729-801-82	TRANSISTOR 2SB1013-2	R147	1-259-404-11	CARBON 100 5% 1/6W
Q519	8-729-104-91	TRANSISTOR 2SA1383-Q	R148	1-259-404-11	CARBON 100 5% 1/6W
Q520	8-729-104-91	TRANSISTOR 2SA1383-Q	R149	1-259-404-11	CARBON 100 5% 1/6W
Q521	8-729-104-18	TRANSISTOR 2SC3514-Q	R150	1-259-404-11	CARBON 100 5% 1/6W
Q522	8-729-190-53	TRANSISTOR 2SA985A	R151	1-259-404-11	CARBON 100 5% 1/6W
Q523	8-729-190-53	TRANSISTOR 2SA985A	R152	1-259-404-11	CARBON 100 5% 1/6W
Q524	8-729-200-56	TRANSISTOR 2SK241GR	R153	1-259-404-11	CARBON 100 5% 1/6W
Q525	8-729-200-56	TRANSISTOR 2SK241GR	R154	1-259-380-11	CARBON 10 5% 1/6W
Q526	8-729-200-56	TRANSISTOR 2SK241GR	R155	1-259-380-11	CARBON 10 5% 1/6W
Q527	8-729-200-56	TRANSISTOR 2SK241GR	R156	1-247-721-11	CARBON 4.7K 5% 1/4W
R001	1-259-401-11	CARBON 75 5% 1/6W	R157	1-247-721-11	CARBON 4.7K 5% 1/4W
R002	1-259-401-11	CARBON 75 5% 1/6W	R160	1-259-420-11	CARBON 470 5% 1/6W
R101	1-259-428-11	CARBON 1K 5% 1/6W	R161	1-259-476-11	CARBON 100K 5% 1/6W
R102	1-259-500-11	CARBON 1M 5% 1/6W	R162	1-259-476-11	CARBON 100K 5% 1/6W
R103	1-259-420-11	CARBON 470 5% 1/6W	R163	1-259-452-11	CARBON 10K 5% 1/6W
R104	1-259-428-11	CARBON 1K 5% 1/6W	R201	1-247-713-11	CARBON 1K 5% 1/4W
R105	1-259-500-11	CARBON 1M 5% 1/6W	R202	1-259-452-11	CARBON 10K 5% 1/6W
R106	1-259-420-11	CARBON 470 5% 1/6W	R203	1-259-452-11	CARBON 10K 5% 1/6W
R107	1-259-416-11	CARBON 330 5% 1/6W	R205	1-247-725-11	CARBON 10K 5% 1/4W
R108	1-259-416-11	CARBON 330 5% 1/6W	R206	1-259-452-11	CARBON 10K 5% 1/6W
R109	1-259-416-11	CARBON 330 5% 1/6W	R207	1-259-452-11	CARBON 10K 5% 1/6W
R110	1-259-420-11	CARBON 470 5% 1/6W	R208	1-247-721-11	CARBON 4.7K 5% 1/4W
R111	1-259-420-11	CARBON 470 5% 1/6W	R209	1-247-721-11	CARBON 4.7K 5% 1/4W
R112	1-259-459-11	CARBON 20K 5% 1/6W	R210	1-249-460-11	CARBON 15K 5% 1/4W
R113	1-259-428-11	CARBON 1K 5% 1/6W	R211	1-247-713-11	CARBON 1K 5% 1/4W
R114	1-259-436-11	CARBON 2.2K 5% 1/6W	R212	1-247-713-11	CARBON 1K 5% 1/4W
R115	1-259-428-11	CARBON 1K 5% 1/6W	R214	1-259-440-11	CARBON 3.3K 5% 1/6W
R116	1-259-420-11	CARBON 470 5% 1/6W	R215	1-259-392-11	CARBON 33 5% 1/6W
R117	1-259-420-11	CARBON 470 5% 1/6W	R216	1-259-416-11	CARBON 330 5% 1/6W
R118	1-259-420-11	CARBON 470 5% 1/6W	R217	1-259-468-11	CARBON 47K 5% 1/6W
R119	1-259-460-11	CARBON 22K 5% 1/6W	R218	1-259-406-11	CARBON 120 5% 1/6W
R120	1-259-476-11	CARBON 100K 5% 1/6W	R219	1-259-420-11	CARBON 470 5% 1/6W
R121	1-259-452-11	CARBON 10K 5% 1/6W	R220	1-259-416-11	CARBON 330 5% 1/6W
R122	1-259-476-11	CARBON 100K 5% 1/6W			

Ref.No.	Part No.	Description			Ref.No.	Part No.	Description				
R221	1-259-563-11	CARBON	2.2K	1%	1/2W	R332	1-259-555-11	CARBON	1K	1%	1/2W
R222	1-259-692-11	CARBON	4.7K	2%	1W	R333	1-259-640-11	CARBON	33	2%	1W
R223	1-259-416-11	CARBON	330	5%	1/6W	R334	1-259-640-11	CARBON	33	2%	1W
R224	1-259-416-11	CARBON	330	5%	1/6W	R335	1-259-652-11	CARBON	100	2%	1W
R225	1-259-416-11	CARBON	330	5%	1/6W	R336	1-247-719-11	CARBON	3.3K	5%	1/4W
R226	1-259-416-11	CARBON	330	5%	1/6W	R338	1-249-794-11	CARBON	470	1%	1/2W
R227	1-247-713-11	CARBON	1K	5%	1/4W	R340	1-249-504-11	CARBON	10	5%	1/4W
R228	1-246-545-00	CARBON	1M	5%	1/4W	R350	1-259-615-11	CARBON	330K	1/2W	
R230	1-259-416-11	CARBON	330	5%	1/6W	R401	1-259-699-11	CARBON	9.1K	2%	1W
R231	1-259-500-11	CARBON	1M	5%	1/6W	R402	1-259-699-11	CARBON	9.1K	2%	1W
R232	1-259-412-11	CARBON	220	5%	1/6W	R403	1-259-699-11	CARBON	9.1K	2%	1W
R240	1-259-579-11	CARBON	10K	1%	1/2W	R404	1-259-699-11	CARBON	9.1K	2%	1W
R241	1-259-420-11	CARBON	470	5%	1/6W	R405	1-259-692-11	CARBON	4.7K	2%	1W
R242	1-259-420-11	CARBON	470	5%	1/6W	R406	1-259-692-11	CARBON	4.7K	2%	1W
R250	1-259-412-11	CARBON	220	5%	1/6W	R407	1-259-692-11	CARBON	4.7K	2%	1W
R251	1-259-412-11	CARBON	220	5%	1/6W	R408	1-259-692-11	CARBON	4.7K	2%	1W
R260	1-259-424-11	CARBON	680	5%	1/6W	R409	1-259-701-11	CARBON	11K	2%	1W
R261	1-259-424-11	CARBON	680	5%	1/6W	R410	1-259-701-11	CARBON	11K	2%	1W
R301	1-259-699-11	CARBON	9.1K	2%	1W	R411	1-259-699-11	CARBON	9.1K	2%	1W
R302	1-259-699-11	CARBON	9.1K	2%	1W	R412	1-259-699-11	CARBON	9.1K	2%	1W
R303	1-259-699-11	CARBON	9.1K	2%	1W	R413	1-259-569-11	CARBON	3.9K	1%	1/2W
R304	1-259-699-11	CARBON	9.1K	2%	1W	R414	1-259-627-11	CARBON	1M	1%	1/2W
R305	1-259-692-11	CARBON	4.7K	2%	1W	R415	1-259-699-11	CARBON	9.1K	2%	1W
R306	1-259-692-11	CARBON	4.7K	2%	1W	R416	1-259-569-11	CARBON	3.9K	1%	1/2W
R307	1-259-692-11	CARBON	4.7K	2%	1W	R417	1-259-627-11	CARBON	1M	1%	1/2W
R308	1-259-692-11	CARBON	4.7K	2%	1W	R418	1-259-699-11	CARBON	9.1K	2%	1W
R309	1-259-701-11	CARBON	11K	2%	1W	R419	1-259-677-11	CARBON	1.1K	2%	1W
R310	1-259-701-11	CARBON	11K	2%	1W	R420	1-259-684-11	CARBON	2.2K	2%	1W
R311	1-259-699-11	CARBON	9.1K	2%	1W	R421	1-216-442-00	CARBON	39K	2%	1W
R312	1-259-699-11	CARBON	9.1K	2%	1W	R422	1-259-652-11	CARBON	100	2%	1W
R313	1-259-569-11	CARBON	3.9K	1%	1/2W	R423	1-259-730-11	CARBON	180K	2%	1W
R314	1-259-627-11	CARBON	1M	1%	1/2W	R424	1-259-713-11	CARBON	36K	2%	1W
R315	1-259-699-11	CARBON	9.1K	2%	1W	R425	1-259-689-11	CARBON	3.6K	2%	1W
R316	1-259-569-11	CARBON	3.9K	1%	1/2W	R426	1-247-723-11	CARBON	6.8K	5%	1/4W
R317	1-259-627-11	CARBON	1M	1%	1/2W	R427	1-249-596-11	CARBON	68K	5%	1/4W
R318	1-259-699-11	CARBON	9.1K	2%	1W	R431	1-259-531-11	CARBON	100	1%	1/2W
R319	1-259-677-11	CARBON	1.1K	2%	1W	R432	1-259-555-11	CARBON	1K	1%	1/2W
R320	1-259-684-11	CARBON	2.2K	2%	1W	R433	1-259-640-11	CARBON	33	2%	1W
R321	1-216-442-00	CARBON	39K	2%	1W	R434	1-259-640-11	CARBON	33	2%	1W
R322	1-259-652-11	CARBON	100	2%	1W	R435	1-259-652-11	CARBON	100	2%	1W
R323	1-259-730-11	CARBON	180K	2%	1W	R436	1-247-719-11	CARBON	3.3K	5%	1/4W
R324	1-259-713-11	CARBON	36K	2%	1W	R437	1-249-794-11	CARBON	470	1%	1/2W
R325	1-259-689-11	CARBON	3.6K	2%	1W	R438	1-249-794-11	CARBON	470	1%	1/2W
R326	1-247-723-11	CARBON	6.8K	5%	1/4W	R440	1-249-504-11	CARBON	10	5%	1/4W
R327	1-249-596-11	CARBON	68K	5%	1/4W	R450	1-259-615-11	CARBON	330K	1/2W	
R331	1-259-531-11	CARBON	100	1%	1/2W	R501	▲.1-212-976-00	FUSIBLE	56	5%	1/2W

The components identified by mark ▲ or dotted line with mark ▲ are critical for safety.  
Replace only with part number specified.

<u>Ref.No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Ref.No.</u>	<u>Part No.</u>	<u>Description</u>						
R502	1-259-601-11	CARBON	82K	1%	1/2W	R548	1-259-555-11	CARBON	1K	1%	1/2W
R503	1-259-547-11	CARBON	470	1%	1/2W	R549	1-217-158-00	RES, METAL PLATE	0.47		
R504	1-259-582-11	CARBON	13K	1%	1/2W	R550	1-217-158-00	RES, METAL PLATE	0.47		
R505	1-259-579-11	CARBON	10K	1%	1/2W	R551	1-217-158-00	RES, METAL PLATE	0.47		
R506	1-259-617-11	CARBON	390K	1%	1/2W	R552	1-217-158-00	RES, METAL PLATE	0.47		
R507	1-259-612-11	CARBON	240K	1%	1/2W	R602	1-259-416-11	CARBON	330	5%	1/6W
R508 $\Delta$	1-219-006-11	FUSIBLE	22	5%	1/2W	R603	1-259-416-11	CARBON	330	5%	1/6W
R509	1-259-563-11	CARBON	2.2K	1%	1/2W	R604	1-259-416-11	CARBON	330	5%	1/6W
R510	1-259-563-11	CARBON	2.2K	1%	1/2W	R701	1-259-644-11	CARBON	47	2%	1W
R511	1-259-571-11	CARBON	4.7K	1%	1/2W	R702	1-259-644-11	CARBON	47	2%	1W
R512	1-259-571-11	CARBON	4.7K	1%	1/2W	R703	1-259-680-11	CARBON	1.5K	2%	1W
R513	1-259-525-11	CARBON	56	1%	1/2W	R704	1-259-644-11	CARBON	47	2%	1W
R514	1-259-525-11	CARBON	56	1%	1/2W	R705	1-259-644-11	CARBON	47	2%	1W
R515	1-259-555-11	CARBON	1K	1%	1/2W	R706	1-259-680-11	CARBON	1.5K	2%	1W
R516	1-259-555-11	CARBON	1K	1%	1/2W	R951	1-247-717-11	CARBON	2.2K	5%	1/4W
R517	1-259-579-11	CARBON	10K	1%	1/2W	R952	1-247-717-11	CARBON	2.2K	5%	1/4W
R518	1-259-555-11	CARBON	1K	1%	1/2W	R953	1-247-717-11	CARBON	2.2K	5%	1/4W
R519	1-259-579-11	CARBON	10K	1%	1/2W	R954	1-247-717-11	CARBON	2.2K	5%	1/4W
R520	1-259-555-11	CARBON	1K	1%	1/2W	R955	1-247-717-11	CARBON	2.2K	5%	1/4W
R521	1-259-559-11	CARBON	1.5K	1%	1/2W	RSW951	1-572-187-11	SWITCH, ROTARY (DIGITAL INPUT)			
R522	1-259-559-11	CARBON	1.5K	1%	1/2W	RV601	1-224-252-XX	RES, ADJ, METAL GLAZE 10K			
R523	1-259-565-11	CARBON	2.7K	1%	1/2W	RY301	1-515-726-11	RELAY			
R524	1-259-565-11	CARBON	2.7K	1%	1/2W	RY302	1-515-726-11	RELAY			
R525	1-259-541-11	CARBON	270	1%	1/2W	RY304	1-515-726-11	RELAY			
R526	1-259-565-11	CARBON	2.7K	1%	1/2W	RY401	1-515-726-11	RELAY			
R527	1-259-531-11	CARBON	100	1%	1/2W	RY402	1-515-726-11	RELAY			
R528	1-259-541-11	CARBON	270	1%	1/2W	RY404	1-515-726-11	RELAY			
R529	1-259-565-11	CARBON	2.7K	1%	1/2W	SSW901	1-571-083-31	SWITCH, SLIDE (BALANCE OUT)			
R530	1-259-531-11	CARBON	100	1%	1/2W	SW701 $\Delta$	1-554-538-00	SWITCH, PUSH (AC POWER)(1 KEY)			
R531	1-259-676-11	CARBON	1K	2%	1W	T101 $\Delta$	1-449-427-11	TRANSFORMER, POWER			
R532	1-259-677-11	CARBON	1.1K	2%	1W	T102 $\Delta$	1-450-196-11	TRANSFORMER, POWER			
R533	1-259-676-11	CARBON	1K	2%	1W	T301	1-424-328-11	TRANSFORMER, LINE			
R534	1-259-677-11	CARBON	1.1K	2%	1W	T401	1-424-328-11	TRANSFORMER, LINE			
R535	1-259-531-11	CARBON	100	1%	1/2W	X101	1-577-269-11	VIBRATOR, CRYSTAL (18.432MHz)			
R536	1-259-531-11	CARBON	100	1%	1/2W	X102	1-466-262-11	MODULE, VCXO			
R537	1-259-531-11	CARBON	100	1%	1/2W	X201	1-577-686-11	VIBRATOR, CRYSTAL			
R538	1-259-531-11	CARBON	100	1%	1/2W	<u>ACCESSORY &amp; PACKING MATERIAL</u>					
R539	1-259-551-11	CARBON	680	1%	1/2W	1-558-271-11	CORD, CONNECTION				
R540	1-259-551-11	CARBON	680	1%	1/2W	1-558-378-11	CORD, CONNECTION				
R541	1-259-551-11	CARBON	680	1%	1/2W	3-751-250-11	MANUAL, INSTRUCTION (ENGLISH,FRENCH,GERMAN,ITALIAN)				
R542	1-259-551-11	CARBON	680	1%	1/2W	*3-703-710-41	STICKER, SONY SYMBOL (12)				
R543	1-259-571-11	CARBON	4.7K	1%	1/2W	4-362-304-00	GUARD, PLUG				
R544	1-259-579-11	CARBON	10K	1%	1/2W	*4-924-262-01	CUSHION				
R545	1-259-543-11	CARBON	330	1%	1/2W	*4-941-349-01	INDIVIDUAL CARTON				
R546	1-259-531-11	CARBON	100	1%	1/2W						
R547	1-212-958-00	CARBON	10	1%	1/2W						

The components identified by mark  $\Delta$  or dotted line with mark  $\Delta$  are critical for safety.  
Replace only with part number specified.